

# **Ames MPF™ 98/100 AQUA**

## **Microplate Format Mutagenicity Assay**

**for the testing of non-concentrated water samples**

**Strains: *S. typhimurium* TA98 and TA100**

---

## **Short Procedure**

**For Research use only**

**Version 2.0 May 2018**

**Please note:** Items are shipped at ambient temperature with cooling elements. Kit contents will be fully active **if shipment is received within 10 days from dispatch and stored immediately as indicated on the individual items and as described on page 3-4 of this manual.** If components are damaged or if any problems occur, please contact Xenometrix by phone: ++41-61-482-14-34; fax: ++41-61-482-20-72, or Email: [info@xenometrix.ch](mailto:info@xenometrix.ch)

## NOTE 1:

---

This manual applies to the following versions of the assay:

| Article No.                                     | Kit size* | lyophilized liver S9 | Positive Controls <sup>#</sup> |
|---|-----------|----------------------|--------------------------------|
| J01-210-S1-P<br>(Aroclor 1254-induced S9)       | 1         | +                    | 2-NF, 4-NQO, 2-AA              |
| J01-210-S2-P<br>(PBN- induced S9 <sup>§</sup> ) | 1         | +                    | 2-NF, 4-NQO, 2-AA              |
| J05-210   | 5         | -                    | -                              |
| J05-210-S1-P<br>(Aroclor 1254-induced S9)       | 5         | +                    | 2-NF, 4-NQO, 2-AA              |
| J05-210-S2-P<br>(PBN-induced S9 <sup>§</sup> )  | 5         | +                    | 2-NF, 4-NQO, 2-AA              |

\* Sufficient for 1 or 5 samples when tested with and without S9, in triplicates, 6 concentrations, with negative and positive controls. This equals a total of 48 (1 sample kit) or 240 measurements (5 sample kit) per strain.

<sup>#</sup> 2-NF: 2-Nitrofluorene; 4-NQO: 4-Nitroquinoline-N-oxide; 2-AA: 2-Aminoanthracene

<sup>§</sup> PBN-induced S9: Phenobarbital /  $\beta$ -naphthoflavone-induced S9

## Changelog:

---

| Date       | New version | Changes   |
|------------|-------------|---|
| 23.05.2018 | 2.0         | <ul style="list-style-type: none"><li>• Changelog added</li><li>• Note 1 added</li><li>• New Assay Procedure graphics</li><li>• Minor text modifications.</li></ul> |

## Principle of the Test

---

Point mutations were made in the histidine operon, rendering the bacteria incapable of producing the corresponding amino acid. These mutations result in *his*- organisms that cannot grow unless histidine is supplied. When a mutagenic event occurs, base substitutions or frameshifts within the gene may cause a reversion to amino acid prototrophy. These reverted bacteria will then grow in a histidine-deficient medium.

A sample's mutagenic potential is assessed by exposing these amino acid-requiring organisms to varying concentrations of water sample and selecting for the reversion event. A medium lacking histidine is used for this selection which allows only those cells that have undergone the reversion to histidine prototrophy to survive and grow.

The available strains are the *Salmonella typhimurium* strains TA98 and TA100, TA100, is for the detection of base substitution mutations and is for the detection of frameshift mutations.

## Assay Description

---

Bacteria are exposed to 6 concentrations of a test agent, as well as a positive and a negative control, for 90 minutes in medium containing sufficient to support approximately two cell divisions. After exposure, the cultures are diluted in pH indicator medium lacking histidine and aliquoted into 48 wells of a 384-well plate. Within two days, cells that have undergone reversion to amino acid prototrophy will grow into colonies. Bacterial metabolism reduces the pH of the medium, changing the color of that well. The number of wells containing revertant colonies are counted for each dose and compared to a solvent (negative) control. Each dose is done in triplicate to allow for statistical analysis of the data.

A dose dependent increase in the number of revertant colonies upon exposure to test sample relative to the solvent control indicates that the sample is mutagenic in the Ames MPF AQUA assay.

The mutagenic potential of samples is assessed directly and in the presence of liver S9 fractions.

## Genotypes of the TA98 & TA100 *Salmonella typhimurium* strains

---

| Strain | Mutation        | Type             | Target   | Cell Wall  | Repair      | pKM101 |
|--------|-----------------|------------------|----------|------------|-------------|--------|
| TA98   | <i>hisD3052</i> | Frameshifts      | GCGCGCGC | <i>rfa</i> | <i>uvrB</i> | yes    |
| TA100  | <i>hisG46</i>   | Base-pair subst. | GGG      | <i>rfa</i> | <i>uvrB</i> | yes    |

*rfa*: This mutation leads to a defective lipopolysaccharide (LPS) layer that coats the cell surface, making the bacteria more permeable to bulky chemicals and non-pathogenic (Mortelsmans and Zeiger (2000), Mutat. Res. 455, 29-60).

*uvrB*: The *uvrB* deletion mutation eliminates the accurate excision repair mechanism, thereby allowing more DNA lesions to be repaired by error-prone DNA repair mechanisms. The deletion through the biotin gene makes the bacteria biotin dependent.

pKM101: This R factor plasmid enhances chemical and UV-induced mutagenesis via an error-prone recombinational DNA repair pathway. The plasmid also confers ampicillin resistance.

## Kit Components and Storage Conditions

---

Each Xenometrix Ames MPF™ 98/100 AQUA Mutagenicity Assay kit contains the following components and should be stored as indicated:

### –70°C to –80°C:

Vials containing *Salmonella* strains (TA100, TA98)

**Note:** When referring to storage at –70°C, we mean that storage at –80°C is also suitable.

**Note:** The bacteria are shipped with cool packs, but not frozen. Upon arrival they must be immediately stored at least at –70°C. Improper storage at –20°C may compromise the viability of the strains. The tubes are not suitable for liquid nitrogen storage.

(If no –70°C storage is available at your institution please contact Xenometrix.)

### –20°C:

Vial(s) containing sterile ampicillin (50 mg/ml)

S9 (if included, see Note 1 at beginning of document for available kit configurations)

Dissolved positive controls

### 4°C:

10× Exposure Medium Solution A

10× Exposure Medium Solution B

Positive controls before reconstitution (if provided, see Note 1 at beginning of document)

### 20 – 25°C (room temperature, protected from light):

Growth Medium

Indicator Medium

## Required Equipment and Consumables NOT Included with the Kit

---

**Note:** all plastic ware has to be sterile!

- Environmental shaker capable of 37°C, 250 rpm incubations
- 37°C dry incubator
- Light table for scoring results (recommended)
- Spectrophotometer for measuring optical density at 600 nm
- 20 µl, 200 µl, and 1000 µl adjustable pipettes and sterile tips
- 5–50 µl and 50–200 µl 8-channel pipettes
- 8-Channel repeating pipettor and sterile tips (highly recommended)
- Optional: Plate reader capable of reading 96-well plates at OD<sub>600</sub> (for cytotoxicity measurement)
  
- 50 ml tubes with (filter) caps
- 24-well plates
- 384-well microtiter plates
- 96-well microtiter plate (optional, for cytotoxicity measurement)
- Reagent reservoirs
- 5 ml and 10 ml pipettes
- Spectrophotometer cuvettes
- Solvents and sterile water for sample dilution
- S9 buffer components\*

### Included in some kit versions only:

- Positive control chemicals
- S9 liver fraction (Aroclor 1254 or Phenobarbital/β-Naphtoflavone-induced)

### \*S9 Cofactor kit (Art. No. PCO-0800)


A ready-to-use kit available separately from Xenometrix containing phosphate buffer pH 7.4, MgCl<sub>2</sub>, KCl, G-6-P and NADP for preparing the S9 mix. This kit replaces the self-made S9 buffer components.

## Safety Precautions

---

- Please consult your local guidelines for handling *S. typhimurium* strains. The strains used in this kit are of low pathogenicity and are generally assigned in Risk Group Level 2. You may consult <http://www.absa.org/riskgroups/bacteria.html> for more information.
- Not for use in humans and animals. For research purposes only.
- Do not drink, eat, smoke, or apply cosmetics in designated work areas. Wear laboratory coats and gloves when handling specimens and kit reagents. Wash hands thoroughly afterwards. Do not pipette by mouth.
- Handle specimens as if capable of transmitting infectious agents. Thoroughly clean and disinfect all materials and surfaces that have been in contact with specimens. Discard all waste associated with specimens in a biohazard waste container.
- Positive control chemicals - although provided in small quantities - are mutagens/carcinogens. Please refer to the corresponding MSDS'.

# Ames MPF Aqua – Assay Procedure



Ames MPF

Ames MPF Aqua  
Assay Procedure

Xenometrix AG